



STYLE (DRAFTING VER.)

SPEC SHEET

Lead Time: 2 - 3 weeks
Warranty: 10 years
Price Range: \$\$\$

Please refer to a physical sample. Images are for an indicative reference only.
Actual product may vary slightly, depending upon model configurations.
Lead time subject to fabric, leather or vinyl supplier's stock availability.

FEATURES	DIMENSIONS	WIDTH (mm)	DEPTH (mm)	HEIGHT (mm)
» Black breathable mesh backrest	Medium Mesh Back	450		440
» Ratchet-back height adjustment	Seat (Gaslift-200)	520	490	540 - 740 (Un-Seated)
» Heavy duty 3-lever mechanism: - Back angle adjustment - Seat angle adjustment - Tilt tension adjustment - Gaslift seat height adjustment	Seat (Gaslift-270)	520	490	600 - 865 (Un-Seated)
» Optional 200mm or 270mm gaslift	Base	660	660	
» Height adjustable foot-ring	Upholstery: Made to order in any fabric, leather or vinyl. House black fabric (shorter lead time)			
» Black 5 star nylon base with standard castors				
» AFRDI Level 6 certified (Severe Commercial Use)				
» Max. user weight capacity: 135kg				

Options - Style Drafting Chair.


Please refer to a physical sample.
 Images are for an indicative reference only.
 Actual product may vary slightly.

One Seat Size only


STANDARD
 520W x 490D
 (Default)

Seat sizes can vary plus or minus
 15mm due to the stretch properties
 of different fabrics and vinyls.

Ergonomic Add-ons




Arms




Height adjustable arms
3D Adjustable arms
 Available on all as
 upgrade

Gaslift




Low gaslift
 Adjustment range of
 80 to 100mm
140mm gaslift
 Adjustment range of
 140mm.
Drafting gaslift - 200
 Adjustment range of
 200mm
Drafting gaslift - 270
 (Default)
 Adjustment range of
 270mm.

Base




Nylon Drafting Base
 with castors
 (Default)




Nylon Drafting Base
 with glides


Castors




Heavy Duty Castors
 Standard castors
 - 60mm
 (Default)



Soft Tyre Castors
 Ideal for hard floors
 - 50mm
 - 60mm



Locking Castors
 Sit-Lock:
 - Locks when user sits
 Stand-lock: (Friction Castors)
 - Locks when no weight is
 on chair.



Brake Castors
 Brake feature is manually
 activated by a small lever
 on the castor.